

BLUE RED MAGENTA GREEN CYAN YELLOW WHITE BLACK VERSION TR-DOS 48 TR-DOx 48 TR-DOx 128 LOAD"" 128 LOAD"" 48

	TEST RTC	MOUSE TEST	Tiny Term	ScanCode TEST	ZX-Keys ON	RESET	NMI	WAIT	GRAPH ScrLk	<> NumLk	KAY-1024			
EDIT	CAPS LOCK	TRUE VIDEO	INV. VIDEO	←	↓	↑	→	GRAPHICS	DELETE	SIN	COS	TAN	INT	RND
1 !	2 @	3 #	4 \$	5 %	6 &	7 ,	8 (9)	0 _	Q PLOT	W DRAW	E REM	R RUN	T RAND
DEF FN	FN	LINE	OPEN	CLOSE #	MOVE	ERASE	POINT	CAT	FORMAT	ASN	ACS	ATN	VERIFY	MERGE
STR \$	CHR \$	CODE	PEEK	TAB	READ	RESTORE	DATA	SGN	ABS	SQR	VAL	LEN	USR	*
Y AND RETURN	U OR IF	I AT INPUT	O POKE	P PRINT	A STOP NEW	S NOT SAVE	D STEP DIM	F TO FOR	G THEN GOTO	H GOSUB	J LOAD	K LIST	L LET	
[]	IN	OUT	©	~		\	{	}	CIRCLE	VAL \$	SCREEN \$	ATTR	
LN	EXP	L PRINT	L LIST	BIN	IN KEY	PI								
Z : COPY	X £ CLEAR	C ? COUNT	V / CLS	B * BORDER	N ' NEXT	M PAUSE	:	;	.	,	/	"	+	-
BEEP	INK	PAPER	FLASH	BRIGHT	OTHER	INVERSE								
EDIT	SYMBOL SHIFT		SYMBOL SHIFT		CAPS SHIFT		CAPS SHIFT		GRAPH	£	TRUE VIDEO	INV. VIDEO		

ZX Keyboard

EDIT	CAPS LOCK	TRUE VIDEO	INV. VIDEO	←	↓	↑	→	GRAPHICS	DELETE	SIN	COS	TAN	INT	RND
1 !	2 @	3 #	4 \$	5 %	6 &	7 ,	8 (9)	0 _	Q PLOT	W DRAW	E REM	R RUN	T RAND
DEF FN	FN	LINE	OPEN	CLOSE #	MOVE	ERASE	POINT	CAT	FORMAT	ASN	ACS	ATN	VERIFY	MERGE
STR \$	CHR \$	CODE	PEEK	TAB	READ	RESTORE	DATA	SGN	ABS	SQR	VAL	LEN	USR	LN
Y AND RETURN	U OR IF	I AT INPUT	O POKE	P PRINT	A STOP NEW	S NOT SAVE	D STEP DIM	F TO FOR	G THEN GOTO	H GOSUB	J LOAD	K LIST	L LET	Z : COPY
[]	IN	OUT	©	~		\	{	}	CIRCLE	VAL \$	SCREEN \$	ATTR	BEEP
EXP	L PRINT	L LIST	BIN	IN KEY	PI	←	→	↑	↓	:	.	,	"	BREAK
X £ CLEAR	C ? COUNT	V / CLS	B * BORDER	N ' NEXT	M PAUSE									
EDIT	TRUE VIDEO	INV. VIDEO	CAPS LOCK	CAPS SHIFT	CAPS SHIFT	EXTEND MODE	SYMBOL SHIFT	SYMBOL SHIFT	TR-DOx 48	DELETE				
GRAPH	1	2	3	4	5	6	7	8	9	0	RESET	RESET		

SDCard HxC Floppy Emulator

RESET	TURBO	MAGIC	POWER	ROM	TAPE	TAPE IN	TAPE OUT	VIDEO	AUDIO	VGA	PRINTER	PARALLEL PORT	RGB	
KEYB.	KEMPSTON	SINCLAIR I	SINCLAIR II	SD-CARD	RGB	S-VIDEO	SCART	PS/2 KEYB.	WORK	PROG.			OFF	
SPEAKERS	AUDIO IN	AUDIO OUT	JOYSTICK I	JOYSTICK II	UP	DWN	SEL	↓	↑	↓	↑	⊞	SET	LOCK
⏪	⏩	⏮	⏭	SPEAKER	FIRE	NMI	MOUSE	RS-232	RS-232	UNLOCK	MUTE		On/Off	
RESET	TURBO	MAGIC	POWER	ROM	TAPE	TAPE IN	TAPE OUT	VIDEO	AUDIO	VGA	PRINTER	PARALLEL PORT	RGB	
KEYB.	KEMPSTON	SINCLAIR I	SINCLAIR II	SD-CARD	RGB	S-VIDEO	SCART	PS/2 KEYB.	WORK	PROG.			OFF	
SPEAKERS	AUDIO IN	AUDIO OUT	JOYSTICK I	JOYSTICK II	UP	DWN	SEL	↓	↑	↓	↑	⊞	SET	LOCK
⏪	⏩	⏮	⏭	SPEAKER	FIRE	NMI	MOUSE	RS-232	RS-232	UNLOCK	MUTE		On/Off	
RESET	TURBO	MAGIC	POWER	ROM	TAPE	TAPE IN	TAPE OUT	VIDEO	AUDIO	VGA	PRINTER	PARALLEL PORT	RGB	
KEYB.	KEMPSTON	SINCLAIR I	SINCLAIR II	SD-CARD	RGB	S-VIDEO	SCART	PS/2 KEYB.	WORK	PROG.			OFF	
SPEAKERS	AUDIO IN	AUDIO OUT	JOYSTICK I	JOYSTICK II	UP	DWN	SEL	↓	↑	↓	↑	⊞	SET	LOCK
⏪	⏩	⏮	⏭	SPEAKER	FIRE	NMI	MOUSE	RS-232	RS-232	UNLOCK	MUTE		On/Off	

ЛЕНИНГРАД
 LENINGRAD

Speccy 2010
Speccy 2007

Speccy 2007
ZX Flash Taper

SDCard HxC Floppy Emulator

SCORPION-256

KAY-1024  SL4/Turbo/v2010

KAY-1024  SL4/Turbo/v2010


KAY-1024 


KAY-1024 SL-4 / TURBO / v2010

KAY-1024

Pent-EVO 

ZX-Evolution 

SPECCY 2007 

SPECCY 2010 


ZXM-PHOENIX


ZXM-PHOENIX

